

Setup Guide - Assembly Information

Your bike will arrive in 3 boxes. **Box 1 = Bike frame & rear wheel, Box 2 = front wheel, Box 3 = battery**

STEP 1

Contents of largest box

STEP 2

Slide handle bar stem into bike

Adjust to height required

Tighten using 6mm Allen Key

Fitting the handle bars

STEP 3

After fitting front wheel remove cover on front right hand forks and connect motor wires (red to red) connect mudguard stay.

Replace cover

Connect motor wires

STEP 4

Connect front brake

STEP 5

Fit chrome bracket & mudguard stay using 5mm Allen Key. Bolts provided on left hand front forks. Tighten wheel nuts both sides.

The black angle bracket is a wire protector & fits on the right hand axle.

STEP 6

Tighten brake bracket to include mudguard fixing lug

Shows mudguard stay on right hand side of forks

STEP 7

Fit battery at base on frame first

Slot battery in at top

STEP 8

After checking all nuts and bolts are tight your bike is ready to ride

*NB - This is a guide only. Your dealer has a pre-delivery inspection procedure that should be carried out before the bike is used.